

Zoroufy Regency Wall Hanger Set Installation Instructions

If you are using a Regency Add-On Set with a Regency Base Set begin with step 1 otherwise start on step 2.

1. Insert one side of the tube connector into open end of the rod. Insert the other side of tube connector into a second rod. Twist the tube connector closed bringing the two rods together to make one continuous rod. Repeat for each Add-On set.
2. Attach finial to rod by inserting rod into the finial base and tightening the small set screw.
3. Slide support brackets onto the rod and attach remaining finial to rod by tightening the small set screw attached to the finial base.
4. Locate desired position of support brackets on the wall making sure the rod is level. A support bracket should be positioned near both ends of the rod and the remaining support bracket(s) should be evenly spaced on the rod.
5. Mark the installation holes of support brackets. Install the support brackets using screws provided. You must use wall anchors suitable for your wall material if screws are not installed into a stud.
6. Attach clips to rug or tapestry and hang by placing clips over the rod.